



Toastrack Style Bike Racks

Installation:

The bike racks should be fixed down using M10 or M12 fixings put through the welded brackets for this purpose. It is the responsibility of the customer to select the appropriate material for fixing the racks – (expansion bolts, sleeve anchors, concrete screws etc) depending on the surface the racks are to be fixed to. Fixing materials are not supplied with the racks. The units should be installed on a level surface and the brackets tightened flush with the ground so that they do not present a trip hazard. The racks should be inspected regularly to ensure that they have not become loose.

The manufacturer cannot be held liable for misuse, incorrect installation or failure to fix down the bike racks correctly.

Defects:

The bike racks are manufactured to the highest standard but we ask our customers and users to inspect the units on receipt of delivery in the case of any defects. All sharp edges should be removed as part of the galvanising process but in the unlikely instance that there are any sharp edges or other defects please contact Castit Limited without delay at 051370393 or email to info@castit.ie

A representative of Castit Limited will call to site to fix any issues if present.